

AUDIOLINE

**Zusätzlicher Handapparat zum
AUDIOLINE DECT7800
Additional handset for the
AUDIOLINE DECT7800**



**Bedienungsanleitung
Operating Instructions**

DECT 7801

AUDIOLINE

DECT 7801

Bedienungsanleitung _____ 3

User Instructions _____ 7

AUDIOLINE

DECT 7801

Diese Zusatzbedienungsanleitung beschreibt die Inbetriebnahme weiterer Handapparate am AUDIOLINE DECT 7800 oder einem anderen DECT/GAP Schnurlostelefonssystem. Allerdings stehen nur in Verbindung mit dem AUDIOLINE DECT 7800 alle Funktionen zur Verfügung, die dieser Handapparat unterstützt.

Hinweis: Für die komplette Bedienungsanleitung inkl. Konformitätserklärung und Sicherheitshinweisen, die auch für dieses Erweiterungsset gelten, nutzen Sie bitte den kostenlosen Download von unserer Website www.audioline.de.

LIEFERUMFANG

In der Verpackung befinden sich folgende Teile:

- Handapparat DECT7800
- Ladestation
- Bedienungsanleitung
- Netzteil
- zwei 1,2V - Standard-Akkus Größe AAA

BATTERIEN EINBAUEN

Öffnen Sie das Batteriefach am Handapparat, indem Sie den Deckel des Batteriefachs durch leichten Druck am unteren Ende vom Handapparat wegschieben. Legen Sie nun die Batterien ein und achten Sie auf die richtige Polung. Schliessen Sie das Batteriefach.

Stellen Sie den Handapparat mit dem Display nach vorne auf die Ladestation. Vor dem ersten Betrieb muss der Handapparat für 16 Stunden ohne Unterbrechung aufgeladen werden.

LADESTATION ANSCHLIESSEN

Stellen Sie die Ladestation für den zweiten Handapparat in der Nähe einer Netzsteckdose auf.

Stecken Sie den runden Stecker des kleineren Netzteils in die Buchse auf der Rückseite der Ladestation und das Steckernetzteil in eine vorschriftsmässig installierte Netzsteckdose mit 230V.

Verwenden Sie aus Sicherheitsgründen nur das mitgelieferte Steckernetzteil

HANDAPPARAT AN BASISSTATION DECT7800 ANMELDEN

1. Basistation DECT7800 vorbereiten

Trennen Sie das Steckernetzteil für einige Sekunden von der Stromversorgung. Nach dem erfolgten Wiederanschluß melden Sie den Handapparat **innerhalb von 20 Sekunden** wie folgt an:

2. Handapparat DETC78010 anmelden

Taste  und zweimal Taste  (3)

drücken. Symbol  blinkt

Mit der Taste  bestätigen.

PIN-Code 1 1 1 1 der DECT7800
Basisstation eingeben.

Bestätigen Sie mit .

Nach einigen Sekunden ist der Handapparat angemeldet.


HANDAPPARAT AN EINE DECT/GAP BASISSTATION ANDEREN SYSTEMS ODER HERSTELLERS ANMELDEN

1. Basistation vorbereiten

Folgen Sie der Bedienungsanleitung der Basisstation unter "Anmelden weiterer Handapparate" an der Sie Ihren neuen Handapparat anmelden wollen.

2. Handapparat DETC7801 anmelden

Verfahren Sie wie vor beschrieben, aber verwenden Sie (an Stelle 1111) den PIN Code der Basisstation an der Sie sich anmelden wollen.

Nach der erfolgten Anmeldung hören Sie einen positiven Bestätigungston und das Symbol  im Display erscheint konstant.

AUDIOLINE

DECT 7801

These supplemental operating instructions describe how install additional handsets with the *AUDIOLINE DECT 7800* and other DECT/GAP cordless telephone systems. However, all functions supported by this handset are available only in conjunction with the AUDIO LINE DECT 7800.

Note: Please refer to the free download in our Website www.audioline.de for complete operating instructions including the declaration of conformity and notes on safety applicable to this extension set.

SCOPE OF SUPPLY

The following parts are enclosed in the package:

- DECT7800 Handset
- Operating instructions
- Two standard 1.2-volt AAA rechargeable batteries
- Charger
- Power supply

INSTALLING THE BATTERIES

Open the battery compartment in the handset by sliding the cover away from the handset by applying a slight amount of pressure to the bottom edge. Now insert the batteries ensuring that the polarity is correct and close the battery cover.

Place the handset in the battery charger with the display facing towards the front. The charger indicator light on the base station and the charger will illuminate. The handset must be charged for an uninterrupted period of 16 hours before using for the first time.

CONNECTING THE CHARGER

Set up the charger for the second handset within reach of an electrical outlet.




Plug the round plug of the smaller power supply in the socket at the back of the charger and plug the transformer plug in a correctly installed 230 volt electrical outlet. For safety reasons, use only the transformer plug supplied.


LOGGING ON A HANDSET TO THE DECT7800 BASE STATION

1. Prepare base station DECT 7800


Disconnect the plug of the power supply for a few seconds. Log on the telephone handset as follows **within 20 seconds** after reconnecting the power supply:

2. Logging on the DECT 7801 handset

Press the  button. Then press the  (3) button twice. The  symbol will flash.

Confirm by pressing the  OK button.

Now enter the PIN code 1 1 1 1 of the DECT7800 base station.

Confirm by pressing  OK.

The handset will be logged on after a few seconds.


LOGGING ON A HANDSET TO ANOTHER DECT/GAP BASE STATION SYSTEM OR A THIRD PARTY BASE STATION

1. Prepare other base station

Follow the operating instructions indicated under 'Logging on additional handsets' of the base station you would like to log on to.

2. Logging on the DECT 7801 handset

Proceed as described above, but use the PIN code of the base station you would like to log on to (instead of 1 1 1 1).

You will hear a positive confirmation tone and the  symbol will appear and remain in the display when the logon is completed.

AUDIOLINE GmbH
Neuss

Service Hotline 0180 5 00 13 88

Internet: www.audioline.de

E-mail: info@audioline.de